



YD-V22 speakerphone
User Manual

www.letsyada.com

WINPLUS

Thank you for purchasing the hands-free Bluetooth® Speakerphone, the latest wireless technology product from Winplus. We hope you will enjoy all the features and benefits offered by the YD-V22 Visor Speakerphone with TTS. These features and benefits were designed with the goal of making wireless communication more convenient for the user.

Winplus USA

820 South Wanamaker Avenue,
Ontario, CA 91761

info@winplususa.com
www.winplususa.com

Winplus Europe

Unit 4, Two Counties Estate, Falconer Road,
Haverhill, Suffolk CB9 7XZ, U.K.

info@winplus-europe.com
www.winplus.net

Winplus Asia

Suites 6-11, 7th Floor, Corporation Park,
11 On Lai Street, Shatin, N.T., Hong Kong

info@winplus.net
www.winplus.net

Winplus Australia

Unit 2, 991 Mountain Hwy Boronia,
Victoria, Australia, 3155

customercare@winplus.com.au
www.winplus.com.au

Winplus New Zealand

Griffiths Equipment
22-24 Olive Road, Penrose,

Auckland, New Zealand
web@griffiths.co.nz
www.types.co.nz

YD-V22 Speakerphone Specifications:

- Talk Time: 10 Hours
- Standby Time: 200 Hours
- Bluetooth® Chip/Class:
CSR chip Bluecore 03 / Class II
- Profiles Support: HSP, HFP, OPP
- Frequency Band:
2402 MHz - 2480 MHz
- Operating Range: 10 Meters
- Operation Voltage: 3.7 VDC
- Battery: Li-ion 3.7V 650mAh
- Audio: (MIC) -60 +/- 2 dB
(Speaker) 8 ohm / 1W
- Input Voltage: 5.0V
- Working Current: 100mA
- Standby Current: 3.5mA
- Operating Temperature: -10°C to 50°C
- Storage Temperature: -20°C to 60°C

CONTENTS

DISCLAIMER

WARRANTY / LIABILITIES

PACKAGE CONTENT

BATTERY OPERATIONS

SPEAKERPHONE OPERATIONS

BUTTON FUNCTIONS AND OPERATION

CARE AND MAINTENANCE

TROUBLE SHOOTING

CUSTOMER SERVICE / CONTACT US PAGE

FCC / ICC

DISCLAIMER

- Distracted driving is dangerous. Always use the Bluetooth® Device in a manner that does not reduce your attention and ability to drive carefully and safely.
- Adhere to all applicable traffic laws and motor vehicle regulations applicable to the device.
- Consult local laws and regulations for any restrictions on installation or use.
- Do not install on or near an airbag. Such installation could interfere with airbag deployment or could cause the product or another object to become a projectile, which could result in serious personal injury to occupants.
- Ensure the product location will not obstruct your vision while driving.
- Turn off the device prior to boarding an aircraft.
- Small parts may be a choking hazard. Do not allow children to play with the device.
- Observe all signs that require an electrical device to be switched off in designated areas. These may include hospitals, blasting areas or potentially explosive atmospheres.

WARRANTY / LIABILITIES

WINPLUS NORTH AMERICA

LIMITED WARRANTY

WINPLUS North America warrants, to the original purchaser, that its products are free from defects in material and workmanship for 90 days from the date of original purchase. Where permitted by law, WINPLUS North America's liability shall be limited to that set forth in this limited express warranty. This limited express warranty shall be the exclusive remedy of the purchaser and WINPLUS North America makes no other warranty of any kind aside from the limited express warranty stated above.

Note: Warranty only applies for North American customers or purchases made in the North America.

CONDITIONS OF WARRANTY

If during the 90 day warranty period your new product is found to be defective, WINPLUS North America will repair such defect, or replace the product, without charge for parts or labor subject to the following conditions:

1. All repairs must be performed by WINPLUS North America.
2. All warranty claims must be accompanied by a copy of the sales receipt or bill of sale.
3. The equipment must not have been altered or damaged through negligence, accident, improper operation, or failure to follow the product instructions for installation, use, or care.
4. The replacement of parts is excluded from the warranty when replacement is necessary due to normal wear and tear.
5. Repair or replacement parts supplied by WINPLUS North America under this warranty are protected only for the unexpired portion of the original warranty.
6. This is a "repair or replace" warranty only, and does not cover the costs incurred for the installation, removal or reinstallation of the product, or damage to any mobile phone device or vehicle.

OWNER'S RESPONSIBILITIES:

WINPLUS North America will make every effort to provide warranty service within a reasonable period of time. **SHOULD YOU HAVE ANY QUESTIONS ABOUT SERVICE RECEIVED OR IF YOU WOULD LIKE ASSISTANCE IN OBTAINING SERVICE, PLEASE CALL TOLL FREE 1.866.294.9244 DURING REGULAR BUSINESS HOURS MONDAY THROUGH FRIDAY 9:00 AM TO 5:00PM.**

In order to provide you with the proper warranty service, we request that you adhere to the following procedure:

1. Include a copy of your sales receipt or bill of sale with your unit when it is returned for warranty service.

2. If it is necessary to return your product for service, please return it securely packed, preferably in the original shipping box, and freight and insurance prepaid to the following address:
ATTN: WINPLUS BLUETOOTH® PRODUCTS RETURNS
820 South Wanamaker Avenue,
Ontario, CA 91761
3. Please include a detailed explanation of the problem you are having.
4. If your product is found by WINPLUS North America to have a defect in material or workmanship, within the warranty period, it will be repaired or replaced at no charge and returned to you prepaid.

WINPLUS North America makes no other warranty of any kind aside from the limited express warranty stated herein.

DISCLAIMER OF WARRANTIES, INCLUDING WARRANTY OF MERCHANTABILITY AND WARRANTY OF FITNESS FOR PARTICULAR PURPOSE: EXCEPT AS SPECIFICALLY SET FORTH HEREIN, NO WARRANTY OR REPRESENTATION, EXPRESS OR IMPLIED, IS MADE AS TO THE YD-V22 VISOR SPEAKERPHONE. EXCEPT AS EXPRESSLY SET FORTH HEREIN, WINPLUS NORTH AMERICA AND/OR ITS AFFILIATES EXPRESSLY DISCLAIMS, WITHOUT LIMITATION, ANY STATUTORY WARRANTIES AND ALL IMPLIED WARRANTIES, INCLUDING ANY IMPLIED WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE.

WINPLUS North America and/or its affiliates are not responsible for a user's intended or actual use of the YD-V22 Visor Speakerphone. In no event shall WINPLUS North America and/or its affiliates have any liability for any losses (whether direct or indirect, in contract, tort or otherwise) incurred in connection with the YD-V22 Visor Speakerphone. Neither shall WINPLUS North America and/or its affiliates have any liability for any decision, action or inaction taken by any person in reliance on the YD-V22 Visor Speakerphone, or for any delays, inaccuracies and/or errors in connection with the YD-V22 Visor Speakerphone and its functioning.

WINPLUS North America and/or its affiliates shall have no responsibility or liability for damage and/or injury resulting from accidents while user is utilizing the YD-V22 Visor Speakerphone; and WINPLUS North America and/or its affiliates, the manufacturer, distributor and seller shall not be liable for any injury, loss or damage, incidental or consequential, arising out of the use or intended use of the product.

WINPLUS EUROPE **LIMITED WARRANTY**

WINPLUS warrants, to the original purchaser, that its products are free from defects in material and workmanship for 12 months from the date of original purchase. Where permitted by law, WINPLUS liability shall be limited to that set forth in this limited express warranty. This limited express warranty shall be the exclusive remedy of the purchaser and WINPLUS makes no other warranty of any kind aside from the limited express warranty stated above.

OWNER'S RESPONSIBILITIES:

In order to provide you with the proper warranty service, we request that you adhere to the following procedure:

1. Include a copy of your sales receipt or bill of sale with your unit when it is returned for warranty service.
2. If it is necessary to return your product for service, please return it securely packed, preferably in the original shipping box, and freight and insurance prepaid to the following address:
ATTN: WINPLUS BLUETOOTH® PRODUCTS RETURNS
Unit 4, Two Counties Estate, Falconer Road
Haverhill, Suffolk CB9 7XZ, UK
3. Please include a detailed explanation of the problem you are having.
4. If your product is found by WINPLUS to have a defect in material or workmanship, within the warranty period, it will be repaired or replaced at no charge and returned to you prepaid.

WINPLUS makes no other warranty of any kind aside from the limited express warranty stated herein.

WINPLUS AUSTRALIA / HONG KONG

LIMITED WARRANTY

This Yada product is warranted against faulty workmanship for a period of 2 years from date of purchase. Liability is limited to replacement of the product and claims for associated or consequential loss or damage will not be accepted. Warranty is void and does not apply if the product has been damaged or rendered faulty by accident, abuse, misuse, incorrect application or if the product has been modified or tampered with. Proof of purchase is required to validate warranty claims. If this product is faulty, simply return it to the place of purchase with your receipt for a replacement product. No refunds or credits will be issued. Replacement is limited to a Yada product of the same or similar model.

PACKAGE CONTENT



Bluetooth® Visor Speakerphone



Car Charger



Visor Clip

BATTERY OPERATIONS

⚠️ IMPORTANT: Before using the YD-V22 Visor Speakerphone:

- Charge the battery before using for the first time


Charging the Battery

Follow the steps below when charging the YD-V22 Visor Speakerphone:

- Plug the charger to the charging port of the battery
- Connect the charger to a power outlet



⚠️ IMPORTANT: Remove device from DC port before leaving the vehicle. Do not leave the YD-V22 Visor Speakerphone charging in the vehicle unattended.

SPEAKERPHONE OPERATIONS



A. Power on/off

To turn YD-V22 on:

- Press and hold the  Button
- TTS will indicate "POWER ON"
- YD-V22 will then enter search mode
- If no device was found, it will switch to standby mode
- To search again, press the  button once
- Search mode is activated
- TTS will indicate "SEARCHING FOR DEVICE"
- If there is no connection in 5 minutes, YD-V22 will automatically power off
- TTS will indicate "POWER OFF"

NOTE: Auto searching will not be activated automatically for first time use. You must successfully connect to YD-V22 at least once in order to activate this feature.

To turn YD-V22 off:

- Press and hold  for 2 seconds
- TTS will indicate "POWER OFF"


B. Pairing/Linking

Pairing Bluetooth® enabled devices like mobile phones with the YD-V22 Visor Speakerphone authorizes the devices to work with each. This step only needs to be performed once.

Before Pairing the YD-V22 Visor Speakerphone:

- Ensure the YD-V22 is fully charged
- The Bluetooth® on your mobile phone is activated

Follow the steps below to pair your YD-V22 with your mobile phone for the first time:


- Make sure the unit is no longer in search mode or press the  once
- Press and hold the **MENU** Button for two seconds
- Device will indicate "ENTER PAIR MODE"
- YD-V22 is now in pairing mode
- Select SET-UP or CONNECT from your mobile phone menu
- Find and select OPTION to discover Bluetooth® devices; establishing a connection may take several minutes
- If found, phone display should indicate YD-V22 device was detected
- Phone should give you a prompt asking if you want to pair the device
- Select OK or ACCEPT and wait for prompt to enter passkey or PIN
- Enter the code 0000
- Select "OK" to pair the YD-V22 and the handset
- TTS will indicate "PAIRING SUCCESSFUL"
- If there is no response in 1 minute, the YD-V22 will auto exit
- TTS will indicate "EXIT PAIR MODE"

NOTE: Under the pairing mode, if the YD-V22 and mobile handset did not successfully pair, follow the steps below to retry pairing:

- Power off the YD-V22 then power on again
- Set off all other Bluetooth® devices before starting the pairing process
- Repeat the pairing instructions from the beginning

Connecting the YD-V22:


Once pairing is successful, you may connect the YD-V22 to your mobile phone:

- Make sure the Bluetooth® has been activated on your mobile phone
- Press  once
- TTS will indicate "BLUETOOTH CONNECTED"

Disconnecting the Bluetooth® link:

- Press  and  simultaneously for two seconds
- TTS will indicate "BLUETOOTH DISCONNECTED"



C. Phone Settings

 **IMPORTANT:** Some set-up functions are only available when the YD-V22 Visor Speakerphone is connected to a device

1. Language Settings

YD-V22 Visor Speakerphone offers 6 languages options, British English, American English, Dutch, Italian, German, Spanish

To select between these 6 languages:

- Press **MENU** once
- TTS will indicate "PRESS SEND BUTTON TO SELECT LANGUAGE"
- TTS will indicate "British English", "American English", "Dutch", "ITALIANO", "DEUTSCH" & "ESPAÑOL"
- Press  to confirm the language
- Press  to cancel

NOTE: If no action was taken, voice prompt will repeat twice and then exit

2. Caller ID Announcement:



IMPORTANT: Caller ID is a network service. Please consult your network provider for details.

There are three types of caller ID announcement:

1. With Name: TTS will indicate "CALL FROM (CALLER'S NAME)"
2. With Number: TTS will indicate "CALL FROM (PHONE NUMBER)"
3. Number Withheld: TTS will indicate "INCOMING CALL"

NOTE: In order for the device to speak out the caller's name during an incoming call, you must transfer the phonebook contact to the unit first

3. Phonebook Setup:



Phone book contents from the mobile can be transferred wirelessly through OPP (Object Push Profile) or AT Command

NOTE: Not all mobile phones support OPP or AT Command features

To transfer the phone book from mobile via AT Command:





- Press + simultaneously for two seconds
- TTS will indicate "PRESS SEND BUTTON TO LOAD CONTACT"
- Press to download or to cancel
- TTS will indicate "TRANSFER IN PROGRESS, PLEASE WAIT" or "CANCEL LOAD CONTACT"
- Blue LED will flash while transferring
- When completed, TTS indicates "LOAD COMPLETE"
- If phonebook transfer failed, TTS will indicate "NO RESPONSE" and will automatically exit

To transfer the Phone book from mobile via OPP function:

- Disconnect the Bluetooth® link from the YD-V22 setting (if it is connected) by pressing and holding  and 
- Do the proper setting on the mobile phone for copying and transferring the contacts from the mobile phone to the YD-V22 (Refer to your mobile phone's user manual)

NOTE: YD-V22 Visor Speakerphone can store up to 500 phone numbers. If it exceeds the maximum capacity, the unit will give a warning message. TTS will indicate "MEMORY FULL". If you are trying to transfer 600 contacts to the YD-V22, only 500 contacts will be successfully transferred.

To delete phone book contents:





- Press  +  simultaneously for two seconds
- TTS will indicate "PRESS SEND BUTTON TO DELETE CONTACT"
- Press  to confirm or press  to cancel
- TTS will indicate "ALL CONTACT DELETED" or "CANCEL DELETE CONTACT"

NOTE: Entire phonebook contents will be deleted

4. Speed Dial Setup

The YD-V22's phonebook has 3 available memory slots for speed dialing. Each slot is represented by the ,  or **MENU** button

To setup speed dialing:

- Press and hold  + either ,  or **MENU** button (The button which you want to set as Speed Dial)
- TTS will indicate "READY FOR CONTACT TRANSFER"
- On your phone, select the phone number you want to set to speed dial & send it to YD-V22 through Bluetooth®
(Please refer to your mobile's operation manual for details)
- Once transfer is successful, the device will emit a tone
- TTS will indicate "PRESS SEND BUTTON TO CONNECT BLUETOOTH"
- Reconnect Bluetooth® link by pressing  or via the mobile
- If transfer failed, the device will exit speed dialing set-up mode after one minute

Note: Some mobile phones support multiple phone numbers under the same contact name. However, the YD-V22 Visor Speakerphone is unable to recognize your preferred number from those contacts. To enable the YD-V22 Visor Speakerphone to recognize the phone number, a contact name should only have one number before transferring to Visor Speakerphone.

D. Operations

1. Making / Receiving Calls


User can make a call either from the mobile phone or the YD-V22 Visor Speakerphone

Before you make or receive calls, ensure:


- Bluetooth® connection is established between YD-V22 and mobile phone
- Battery is fully charged

a. Answering Calls

NOTE: Calls may be answered via the mobile handset in the normal way.
To answer calls via the YD-V22:


- Check if power is on and device is linked
- Press  when ring tone is heard

b. Rejecting Calls

- Press  to reject a call
- TTS will indicate "CALL ENDED"


c. Last Number Re-dial

To call last number dialed or called register:

- Press  twice
- The YD-V22 will automatically dial the last dialed number
- TTS will indicate "LAST NUMBER REDIAL"


d. Voice Dialing

To enter voice dialing mode:



- Hold  for 2 seconds
- TTS will indicate "VOICE DIAL"
- Say the desired name after the tone

NOTE: Phonebook must be transferred to the unit to activate this function

e. Call Waiting

 **IMPORTANT:** Availability of this feature depends on your network service provider

To accept a new call during a conversation:

- Press 
- Line will automatically switch to Line 2
- Press  to switch between the two lines



f. Interchanging YD-V22 and Handset

You may interchange the call between your handset and YD-V22 while conversation is ongoing

- Press and hold  for 2 seconds



g. Volume Adjustments

To adjust the volume during a call:

- Press  to increase speaker volume
- Press  to decrease speaker volume

NOTE: When you have reached the maximum or minimum volume, TTS will indicate "MAXIMUM VOLUME" or "MINIMUM VOLUME"

To adjust Mic volume:





- To increase Microphone Gain, press and hold  for two seconds
- TTS will indicate "MICROPHONE GAIN HIGH"
- To decrease Microphone Gain, press and hold  for two seconds
- TTS will indicate "MICROPHONE GAIN LOW"










h. Mute/Un-mute Functions:

To Mute/Un-mute the YD-V22 during an active call:

- Press **MENU** button
- TTS will indicate "MUTE" or "UNMUTE"

BUTTON FUNCTIONS AND OPERATION

Button	Function	Operation
	Yes / Select	Press 1 time
	Bluetooth® Link / Connect	Press 1 time
	Voice Dial	Press and hold
	Last number redial	Double click
	Receive Call	Once ring tone is heard, press one time
	Conversation transfer	Press and hold
	Call Waiting	Press one time
	Power On	Under off mode, press & hold
	Power Off	Under standby mode, press & hold
	Reject / End call	Press 1 time
	NO / Exit / cancel selected item	Press 1 time
	Increase Volume	Press repeatedly until you reach desired volume
	Scroll up/left menu	Press repeatedly until you reach desired menu item
	Increase Mic Gain	Press and hold
	Speed Dialing Slot 1	Press and hold
	Decrease Volume	Press repeatedly until you reach desired volume
	Scroll down/right menu	Press repeatedly until you reach desired menu item
	Decrease Mic Gain	Press and hold
	Speed Dialing Slot 2	Press and hold

Button	Function	Operation
MENU	Enter Language Selection	Press 1 time
	Pairing Mode	Press and hold
	Mute or Unmute	Press 1 time
	Speed Dialing Slot 3	Press and hold
 + 	Disconnect Bluetooth®	Press and hold
 + 	Transfer Phonebook by AT Command	Press and hold
 + MENU	Set contact for speed dialing	Press and hold
 + 	Set contact for speed dialing	Press and hold
 + 	Set contact for speed dialing	Press and hold

CARE AND MAINTENANCE

- Turn off the YD-V22 when not in use
- Do not let the YD-V22 be in contact with liquid as it is not waterproof. Avoid putting it in places where there is excessive moisture and humidity.
- Do not expose the YD-V22 to direct sunlight nor place in areas with high temperature, as it may result in an explosion
- If the YD-V22 is not in use for a prolonged period, store in a cool, dry place, free from moisture, humidity and dust
- Do not use abrasive cleaning solvents to clean the YD-V22
- Do not expose the YD-V22 to contact with sharp objects as this will cause scratching and damage
- Do not stick anything inside the YD-V22 as this may damage internal components
- Do not attempt to disassemble the YD-V22, as it does not contain serviceable components

- Only use the manufacturer supplied charger when charging the YD-V22
- Only charge the YD-V22's built-in battery in accordance with the instructions of this user guide
- Do not disassemble the charger as it may expose you to dangerous voltages or other risks. Incorrect reassembly can cause electric shock when the YD-V22 is subsequently used
- Do not use the charger outdoors or in damp areas
- Avoid charging the YD-V22 in extremely high or low temperatures
- It's recommended to charge the YD-V22 immediately whenever low battery power is encountered to prolong durability & standby time of battery

TROUBLE SHOOTING

If you are unable to hear the person on the other line clearly, do the following steps while conversation is ongoing:

- Adjust the microphone gain to maximum in your YD-V22 or
- Request the person on the other line to adjust his/her mobile phone volume to maximum

If there is a strong echo resonating from the person on the other line:

- Transfer the call to mobile phone. If echo disappeared, transfer the call again from mobile phone to YD-V22 and lower the loudspeaker volume until echo is eliminated. If the echo still remains, this means the echo is generated by the network service provider or mobile phone itself.

If the speaker volume of the YD-V22 is too low or too high and seems impossible to adjust it:


- Adjust the volume directly on the phone
- Fine tune it using the volume control of the YD-V22

If audio is lost:

- Turn the YD-V22 off and on again
- If this does not solve the problem, press the reset button (all data will be lost)

If the number dialed from the mobile phone couldn't be found on the Call Register of the YD-V22:

- YD-V22 is unable to save numbers dialed directly from the mobile phone



If all buttons are disabled:

- Reset the YD-V22 by pressing and holding the reset button for a minimum of 2 seconds

If the YD-V22 is not functioning after auto-reconnection:


- Restart your mobile and connect again.
- If the problem is not solved, restart YD-V22 as well

If you are unable to connect your speakerphone and mobile handset, please try the following:

- Ensure the YD-V22 is paired with your mobile handset/PC & battery is fully charged
- Ensure your mobile handset's Bluetooth® feature is activated. Please refer to your mobile handset user guide for specific instructions
- If your computer does not have built-in Bluetooth® capability, you will need to install a Bluetooth® USB Adapter to utilize the Speakerphone. Follow instructions for installing adapter in your computer
- Ensure the YD-V22 is within a maximum of 10 meters of your mobile handset(s) or Bluetooth® enabled device and there are no obstructions, such as wall or other electronic devices, in between as it may cause interference transmission

Some problems the YD-V22 may encounter with particular mobile phone models:

1. For Most Nokia Phones:

When transferring a call from the YD-V22 to your mobile, Bluetooth® will be disconnected. To reconnect, simply press 

2. LG KG800

When your mobile is connected to the YD-V22, only HSP profile is supported, some HFP functions are disabled (such as rejecting incoming call, DTMF, call transfer)

3. Samsung E870

When transferring calls to and from the phone, your mobile phone will request for confirmation.

4. Samsung G600

The Samsung G600 does not support call waiting or swapping

The YD-V22 Visor Speakerphone is compliant with and adopts the Bluetooth® Specification V2.0. However, interoperability between the device and other Bluetooth®-enabled products is not guaranteed because it depends on compatibility. For more information on the compatibility between the device and other Bluetooth®-enabled products, please contact Customer Service.

CUSTOMER SERVICE / CONTACT US PAGE

For questions or issues regarding the product, please visit www.letsyada.com or contact Winplus in your area/region to speak to our customer service representative:

Winplus USA

Tel. 866-294-9244

Tel. 310-638-0588

Winplus Europe

Tel. 44-1440-713888

Winplus Australia

Tel. 61-3-9720-4143

Winplus New Zealand

Tel. 64-9-5254575

Winplus Asia

Tel. 852-2798-8932

You can also contact us online by visiting www.winplus.com for more information about the product.

IF YOU ARE EXPERIENCING ANY ISSUES WITH THE PRODUCT DURING OPERATION, DO NOT RETURN THE PRODUCT TO THE STORE. CONTACT WINPLUS DIRECTLY FOR INSTRUCTIONS ON HOW TO RETURN/EXCHANGE THE PRODUCT.

FCC/ ICC

Federal Communication Commission Interference Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one of the following measures:

- Reorient or relocate the receiving antenna.
 - Increase the separation between the equipment and receiver.
 - Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
 - Consult the dealer or an experienced radio/TV technician for help.
- This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

FCC Caution: Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment.

IMPORTANT NOTE:

FCC Radiation Exposure Statement:

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. End users must follow the specific operating instructions for satisfying RF exposure compliance.

This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

IC statement

Operation is subject to the following two conditions:

- 1) This device may not cause interference and
- 2) This device must accept any interference, including interference that may cause undesired operation of the device.

This device has been designed to operate with an antenna having a maximum gain of 0 dBi. Antenna having a higher gain is strictly prohibited per regulations of Industry Canada. The required antenna impedance is 50 ohms.

IMPORTANT NOTE:

IC Radiation Exposure Statement:

This equipment complies with IC radiation exposure limits set forth for an uncontrolled environment. End users must follow the specific operating instructions for satisfying RF exposure compliance.

This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.



WINPLUS

NORTH AMERICA	820 South Wanamaker Avenue Ontario, CA 91761	Tel: 310-638-0588 Fax: 310-496-2740
EUROPE	Unit 4, Two Counties Estate, Falconer Road, Haverhill, Suffolk CB9 7XZ, U.K.	Tel: 44-1440-713888 Fax: 44-1440-713889
AUSTRALIA	Unit 2, 991 Mountain Hwy Boronia, Victoria, Australia, 3155	Tel: 61-3-9720-4143 Fax: 61-3-9720-4165
NEW ZEALAND	22-24 Olive Road, Penrose, Auckland, New Zealand	Tel: 64-9-5254575 Fax: 64-9-5256817
ASIA	Suites 6-11, 7th Floor, Corporation Park, 11 On Lai Street, Shatin, N.T., Hong Kong	Tel: 852-2798-8932 Fax: 852-2795-0241

© 2009 Winplus North America Inc. All Rights Reserved. Winplus, the logo design, and yada are trademarks or registered trademarks of Winplus North America Inc. The Bluetooth® word mark and logos are owned by the Bluetooth SIG, Inc. and any use of such marks by Winplus North America Inc. is under license.